

EDGE



SECURITY
BRANDS

DIRECT PROGRAMMING MANUAL

27-210, 27-215, 27-220(HID/SK),
27-225(HID/SK), 27-230(HID/SK), 27-240



SECURITY BRANDS INC

www.ShopAmericanAccess.com | (800) 878-7829 | Sales@ShopAmericanAccess.com



EDGE SMART KEYPADS AND CARD READERS

Direct Programming Manual

Applicable Models

27-210, 27-215, 27-220, 27-220HID, 27-220SK, 27-225, 27-225HID, 27-225SK,
27-230, 27-230HID, 27-230SK, 27-240

Table of Contents

- Introduction** _____ **3**
- Overview** _____ **3**
- Glossary** _____ **3**
- Programming** _____ **4**
- Direct Programming Input Format** _____ **4**
- Sub Modes Overview** _____ **4**
- Default Configuration** _____ **5**
- Audible Tone Feedback** _____ **6**
- Programming Procedures** _____ **6**
- Add Access Code(s) to Relay A _____ 6
- Delete Code _____ 6
- Change Master Code _____ 7
- Enable/Disable Relays _____ 7
- Add Latch Code to Relay B _____ 7
- Change Sleep Code _____ 7
- Change Code Length _____ 8
- Change Relay Trigger Time _____ 8
- Enable/Disable Timers and Schedules _____ 8
- Enable/Disable "3 Strikes, You're Out" _____ 9
- Configure Event Input 1 _____ 9
- Add Latch Code to Relay A _____ 12
- Add Access Code(s) to Relay A on Both Wiegand Inputs _____ 12
- Add Access Code(s) to Relay A on Wiegand Input 1 _____ 15
- Add Access Code(s) to Relay A on Wiegand Input 2 _____ 17
- Add Manager Access Code(s) to Relay A on Both Wiegand Inputs _____ 19
- Add Manager Access Code(s) to Relay A on Wiegand Input 1 _____ 21
- Add Manager Access Code(s) to Relay A on Wiegand Input 2 _____ 23
- Add Sleep Code(s) on Both Wiegand Inputs _____ 26
- Add Sleep Code(s) on Wiegand Input 1 _____ 28
- Add Sleep Code(s) on Wiegand Input 2 _____ 30

- Add Latch Code(s) to Relay A on Both Wiegand Inputs _____ 32
- Add Latch Code(s) to Relay A on Wiegand Input 1 _____ 35
- Add Latch Code(s) to Relay A on Wiegand Input 2 _____ 37
- Add Access Code(s) to Relay B on Both Wiegand Inputs _____ 39
- Add Access Code(s) to Relay B on Wiegand Input 1 _____ 41
- Add Access Code(s) to Relay B on Wiegand Input 2 _____ 44
- Add Latch Code(s) to Relay B on Both Wiegand Inputs _____ 46
- Add Latch Code(s) to Relay B on Wiegand Input 1 _____ 48
- Add Latch Code(s) to Relay B on Wiegand Input 2 _____ 50
- Change Default Facility Code _____ 53
- Add Split-Relay Access Code on Wiegand Inputs _____ 53
- Add Split-Relay Latch Code on Wiegand Inputs _____ 55
- Delete Code(s) on Both Wiegand Inputs _____ 57
- Delete Code(s) on Wiegand Input 1 _____ 59
- Delete Code(s) on Wiegand Input 2 _____ 61
- Set Unit Clock Time _____ 64
- Set Unit Clock Date _____ 64
- Configure Split-Relay Function _____ 64
- Toggle Silent Mode _____ 66
- Configure Anti-Passback _____ 66
- Configure Wiegand Inputs _____ 69
- Configure Wiegand Bit Format _____ 70
- Configure Wiegand Code Scheme _____ 71
- Configure Wiegand Validation Method _____ 72
- Change Wiegand Code Length _____ 72
- Add Access Code(s) to Relay B _____ 73
- Add Limited-Use Code _____ 73
- Enter Pairing Mode _____ 74
- Delete All Codes and Timers _____ 74
- Master Code Reset _____ 74
- Unit Reset _____ 75
- Technical Support _____ 75**

Introduction

Overview

This manual covers in detail how to carry out all programming functions on all Edge Smart Keypad and Card Reader systems directly via the onboard keypad.

Glossary

Access Card/Code

A card/code used to trigger a relay for a configurable trigger time and open a gate or door.

Anti-Passback

An access control scheme designed to prevent access for individuals to whom access has not been properly granted.

Latch Card/Code

A card/code used to latch a relay and hold a gate or door open if the relay is off and unlatch a relay allowing a gate or door to close if the relay is on. It toggles the current relay state.

Manager Card/Code

A card/code that remains functional even when the unit is in Sleep Mode.

Master Code

A four-digit code used for programming.

Programming Mode

An operation mode on the Edge unit that allows the unit to be programmed, allowing access control administration and management as well as configuration of features and connected devices.

Silent Mode

An operation mode on the Edge unit that disables all audible tones.

Sleep Card/Code

A card/code used to enable/disable Sleep Mode.

Sleep Mode

An operation mode on the Edge unit that disables acceptance of all access and latch cards and codes, event inputs, and tones. Only manager cards/codes are functional while Sleep Mode is active.

Wiegand

A communications protocol used in access control, which allows keypads, proximity card readers, remotes, and vehicle tag readers connected to a primary controller to be managed by the controller.

Programming

Direct Programming Input Format

All direct programming procedures involve entering the Master Code at the Edge unit to enter Programming Mode, entering the Sub Mode, entering additional Sub Modes (depending on feature), entering the parameter value(s), and pressing the pound key (#) to exit programming.

Sub Modes Overview

Sub Mode	Sub Mode 2	Programming Feature
1	-	Add Access Code(s) to Relay A
2	-	Delete Code
3	-	Change Master Code
4	2	Enable/Disable Relays
4	3	Add Latch Code to Relay B
4	4	Change Sleep Code
4	5	Change Code Length
4	6	Change Relay Trigger Time
4	7	Enable/Disable Timers and Schedules
4	8	Enable/Disable "3 Strikes, You're Out"
4	9	Configure Event Input 1
5	-	Add Latch Code to Relay A
6	100	Add Wiegand Access Code(s) to Relay A
6	101	Add Wiegand Manager Code(s) to Relay A
6	102	Add Wiegand Sleep Code(s)
6	103	Add Wiegand Latch Code(s) to Relay A
6	104	Add Wiegand Access Code(s) to Relay B
6	105	Add Wiegand Latch Code(s) to Relay B
6	106	Change Default Facility Code
6	107	Add Wiegand Split-Relay Access or Latch Code(s)
6	200	Delete Wiegand Code(s)
6	302	Set Unit Clock Time
6	303	Set Unit Clock Date
6	307	Configure Split-Relay Function
6	309	Toggle Silent Mode
6	310	Configure Anti-Passback
6	500	Configure Wiegand Inputs
6	501	Configure Wiegand Bit Format on Both Wiegand Inputs

6	502	Configure Wiegand Bit Format on Wiegand Input 1
6	503	Configure Wiegand Bit Format on Wiegand Input 2
6	504	Configure Wiegand Code Scheme
6	505	Configure Wiegand Validation Method
6	506	Configure Wiegand Code Length
7	-	Add Access Code(s) to Relay B
8	-	Add Limited-Use Code
9	-	Enter Pairing Mode
0	-	Delete All Codes

Default Configuration

Feature/Parameter	Value
Master Code	1251
Sleep Code	1985
Relay A Manager Access Code	1366
Relay A Manager Latch Code	1273
Relay A Manager Unlatch Code	1381
Relay B Manager Access Code	1752
Relay B Manager Latch Code	1678
Relay B Manager Unlatch Code	1387
Access/Latch Code Length	4 digits
Relay Trigger Time	5 seconds
Keypad Press-to-Press Timeout	5 seconds
Programming Timeout	15 seconds
Timers and Schedules	Enabled
"3 Strikes, You're Out"	Disabled
Event and Digital Inputs	Disabled
Wiegand Inputs	Disabled
Split-Relay Function	Disabled
Anti-Passback	Disabled
Silent Mode	Disabled

Audible Tone Feedback

All Edge units produce audible tone feedback for key presses, correct entries, incorrect entries, and to confirm a cleared entry as detailed below. Audible feedback is also used for feature status/mode.

- **Good Tone:** sounds when a correct control or programming entry is received by the Edge unit.
- **Bad Tone:** sounds when an incorrect control or programming entry is received by the Edge unit. The tone is reminiscent of a buzzer.
- **Key Tone:** sounds every time a key is pressed on the Edge unit keypad.
- **Clear Tone:** sounds to confirm the entry has been cleared when the star (*) key is pressed on the keypad to clear an unwanted or mistaken entry.

Programming Procedures

All procedures must be entered using the keypad on the Edge unit. Make sure the unit sounds tones with every key press. Otherwise the unit may be powered off, in Sleep Mode, or having an issue.

Add Access Code(s) to Relay A

This procedure will add one or more access codes to Relay A.

Note: By default, the following codes are reserved for other functions and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 1 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 1 and listen for good tone.
3. Enter code (4 digits by default; numbers only) to be added and listen for good tone.
4. Repeat above step to add additional codes.
5. Enter # key to exit Programming Mode.

Delete Code

This procedure will delete a specified code (access and latch codes only; no Wiegand codes).

1251 → 2 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 2 and listen for good tone.
3. Enter code to be deleted and listen for good tone.
4. Enter # key to exit Programming Mode.

Change Master Code

This procedure will change the current Master Code.

Note: By default, the following codes are reserved for other functions and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 3 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 3 and listen for good tone.
3. Enter new Master Code (4 digits; numbers only) and listen for good tone.
4. Enter # key to exit Programming Mode.

Enable/Disable Relays

This procedure will enable or disable Relay A or B.

1251 → 4 → 2 → X → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 2 and listen for good tone.
4. Enter 1 (for Relay A) or 2 (for Relay B).
5. Enter 1 (to enable) or 2 (to disable).
6. Enter # key to exit Programming Mode.

Add Latch Code to Relay B

This procedure will add a latch code to Relay B.

Note: By default, the following codes are reserved for other functions and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 4 → 3 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 3 and listen for good tone.
4. Enter code (4 digits by default; numbers only) to be added and listen for good tone.
5. Enter # key to exit Programming Mode.

Change Sleep Code

This procedure will change the sleep code.

Note: By default, the following codes are reserved for other functions and cannot be used:

1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 4 → 4 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 4 and listen for good tone.
4. Enter new sleep code (4 digits; numbers only) and listen for good tone.
5. Enter # key to exit Programming Mode.

Change Code Length

This procedure will change the code length for non-Wiegand codes from 4 to 11 digits.

❗ IMPORTANT! COMPLETING THIS PROCEDURE WILL DELETE ALL ACCESS AND LATCH CODES!

1251 → 4 → 5 → XX → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 5 and listen for good tone.
4. Enter code length (04 to 11) and listen for good tone.
5. Enter Master Code and listen for good tone.
6. Enter # key to exit Programming Mode.

Change Relay Trigger Time

This procedure will change the relay trigger time for Relay A or B from 1 to 999 seconds.

1251 → 4 → 6 → X → XXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 6 and listen for good tone.
4. Enter 1 (for Relay A) or 2 (for Relay B) and listen for good tone.
5. Enter trigger time in seconds (001 to 999) and listen for good tone.
(e.g., 10 seconds would be entered as 010.)
6. Enter # key to exit Programming Mode.

Enable/Disable Timers and Schedules

This procedure will enable or disable timers and schedules.

1251 → 4 → 7 → 1 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 7 and listen for audible feedback.
Single tone means feature is enabled.
Double tone means feature is disabled.
4. Enter 1 (for no change) or 2 (to change current state) and listen for good tone.
5. Enter # key to exit Programming Mode.

Enable/Disable “3 Strikes, You’re Out”

This procedure will enable or disable “3 Strikes, You’re Out” security. When enabled, the Edge unit will sound an alarm and go into a 90-second period of lockdown when an incorrect code is entered three times on the keypad.

1251 → 4 → 8 → 1 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 8 and listen for status tones.
One tone: feature is enabled.
Two tones: feature is disabled.
4. Enter 1 (for no change) or 2 (to change current state) and listen for good tone.
5. Enter # key to exit Programming Mode.

Configure Event Input 1

This procedure will enable and configure Event Input 1.

Note: To configure other inputs, use the Edge Smart Keypad app.

Mode 0

When this mode is active, Event Input 1 is disabled.

1251 → 4 → 9 → 0 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 9 and listen for status tones:
Good tone: Event Input 1 is disabled (Mode 0).
One tone: Mode 1 enabled.
Two tones: Mode 2 enabled.
Three tones: Mode 3 enabled.

Four tones: Mode 4 enabled.

Five tones: Mode 5 enabled.

4. Enter 0 and listen for good tone.
5. Enter # key to exit Programming Mode.

Mode 1

When this mode is active, the selected relay will be triggered when the state of Event Input 1 changes from normally open (N/O) to normally closed (N/C).

1251 → 4 → 9 → 1 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 9 and listen for status tones:
 - Good tone: Event Input 1 is disabled (Mode 0).
 - One tone: Mode 1 enabled.
 - Two tones: Mode 2 enabled.
 - Three tones: Mode 3 enabled.
 - Four tones: Mode 4 enabled.
 - Five tones: Mode 5 enabled.
4. Enter 1 for Mode 1 and listen for good tone.
5. Enter 1 (for Relay A) or 2 (for Relay B) and listen for good tone.
6. Enter # key to exit Programming Mode.

Mode 2

When this mode is active, a log entry of the event input state will be made when the state of Event Input 1 changes from normally open (N/O) to normally closed (N/C).

1251 → 4 → 9 → 2 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 9 and listen for status tones:
 - Good tone: Event Input 1 is disabled (Mode 0).
 - One tone: Mode 1 enabled.
 - Two tones: Mode 2 enabled.
 - Three tones: Mode 3 enabled.
 - Four tones: Mode 4 enabled.
 - Five tones: Mode 5 enabled.
4. Enter 2 for Mode 2 and listen for good tone.
5. Enter # key to exit Programming Mode.

Mode 3

This mode is a combination of Modes 1 and 2.

1251 → 4 → 9 → 3 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 9 and listen for status tones:
Good tone: Event Input 1 is disabled (Mode 0).
One tone: Mode 1 enabled.
Two tones: Mode 2 enabled.
Three tones: Mode 3 enabled.
Four tones: Mode 4 enabled.
Five tones: Mode 5 enabled.
4. Enter 3 for Mode 3 and listen for good tone.
5. Enter 1 (for Relay A) or 2 (for Relay B) and listen for good tone.
6. Enter # key to exit Programming Mode.

Mode 4

When this mode is active, the selected relay will be enabled when the state of Event Input 1 changes from normally open (N/O) to normally closed (N/C). Otherwise the relay is disabled.

1251 → 4 → 9 → 4 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 9 and listen for status tones:
Good tone: Event Input 1 is disabled (Mode 0).
One tone: Mode 1 enabled.
Two tones: Mode 2 enabled.
Three tones: Mode 3 enabled.
Four tones: Mode 4 enabled.
Five tones: Mode 5 enabled.
4. Enter 4 for Mode 4 and listen for good tone.
5. Enter 1 (for Relay A) or 2 (for Relay B) and listen for good tone.
6. Enter # key to exit Programming Mode.

Mode 5

When this mode is active, the selected relay will be triggered or latched when the state of Event Input 1 changes from normally closed (N/C) to normally open (N/O).

(The default configuration is Relay B trigger.)

1251 → 4 → 9 → 5 → X → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 4 and listen for good tone.
3. Enter secondary sub mode 9 and listen for status tones:
 - Good tone: Event Input 1 is disabled (Mode 0).
 - One tone: Mode 1 enabled.
 - Two tones: Mode 2 enabled.
 - Three tones: Mode 3 enabled.
 - Four tones: Mode 4 enabled.
 - Five tones: Mode 5 enabled.
4. Enter 5 for Mode 5 and listen for good tone.
5. Enter 1 (for relay selection) or 2 (for relay operation selection) and listen for good tone.
6. *Relay Selection*: Enter 0 (for Relay A) or 1 (for Relay B) and listen for good tone.
Relay Operation Selection: Enter 0 (for trigger) and 1 (for latch) and listen for good tone.
7. Enter # key to exit Programming Mode.

Add Latch Code to Relay A

This procedure will add a latch code to Relay A.

Note: By default, the following codes are reserved for other functions and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 5 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 5 and listen for good tone.
3. Enter code (4 digits by default; numbers only) to be added and listen for good tone.
4. Enter # key to exit Programming Mode.

Add Access Code(s) to Relay A on Both Wiegand Inputs

These procedures will add an access code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 100 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 100 and listen for good tone.
4. Enter next sub mode 1 and listen for good tone.
5. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
6. Repeat above step to add additional codes.
7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 100 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 100 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit access code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 100 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 100 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting access code and listen for good tone.
7. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 100 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 100 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be added twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

Add Access Code(s) to Relay A on Wiegand Input 1

These procedures will add an access code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 100 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 100 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 100 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting access code and listen for good tone.
8. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 100 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.

- Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Access Code(s) to Relay A on Wiegand Input 2

These procedures will add an access code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 100 → 1 → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.
- Enter sub mode 6 and listen for good tone.
- Enter 2 (for Wiegand Input 2). No tone will sound.
- Enter next sub mode 100 and listen for good tone.
- Enter next sub mode 1.
- Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
- Repeat above step to add additional codes.
- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 100 → 2 → XXX → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 100 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting access code and listen for good tone.
8. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a

Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 100 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 100 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Manager Access Code(s) to Relay A on Both Wiegand Inputs

These procedures will add a manager access code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

Note: If the split relay feature is enabled, codes will be added per that configuration.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more manager access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 101 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 101 and listen for good tone.
4. Enter next sub mode 1 and listen for good tone.
5. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
6. Repeat above step to add additional codes.
7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more manager access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 101 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 101 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit manager access code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add manager access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 101 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 101 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting manager access code and listen for good tone.
7. Enter 5-digit ending manager access code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more manager access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 101 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 101 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be added twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

Add Manager Access Code(s) to Relay A on Wiegand Input 1

These procedures will add a manager access code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

Note: If the split relay feature is enabled, codes will be added per that configuration.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more manager access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 101 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.

4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more manager access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 101 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit manager access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add manager access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 101 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.

4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting manager access code and listen for good tone.
8. Enter 5-digit ending manager access code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more manager access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 101 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

Add Manager Access Code(s) to Relay A on Wiegand Input 2

These procedures will add a manager access code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

Note: If the split relay feature is enabled, codes will be added per that configuration.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more manager access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 101 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more manager access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 101 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit manager access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add manager access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 101 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting manager access code and listen for good tone.
8. Enter 5-digit ending manager access code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more manager access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 101 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 101 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.

- Wiegand input is configured to share code list with non-Wiegand codes.

Add Sleep Code(s) on Both Wiegand Inputs

These procedures will add a sleep code or codes for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more sleep codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 102 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 102 and listen for good tone.
4. Enter next sub mode 1 and listen for good tone.
5. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
6. Repeat above step to add additional codes.
7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more sleep codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 102 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 102 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit sleep code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add sleep codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 102 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 102 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting sleep code and listen for good tone.
7. Enter 5-digit ending sleep code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 102 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 102 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be added twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.

Add Sleep Code(s) on Wiegand Input 1

These procedures will add a sleep code or codes for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more sleep codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 102 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more sleep codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 102 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.

5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit sleep code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add sleep codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 102 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting sleep code and listen for good tone.
8. Enter 5-digit ending sleep code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more sleep codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 102 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Sleep Code(s) on Wiegand Input 2

These procedures will add a sleep code or codes for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more sleep codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 102 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.

- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more sleep codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 102 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit sleep code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add sleep codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 102 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting sleep code and listen for good tone.
8. Enter 5-digit ending sleep code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more sleep codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 102 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 102 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Latch Code(s) to Relay A on Both Wiegand Inputs

These procedures will add a latch code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 103 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 103 and listen for good tone.

4. Enter next sub mode 1 and listen for good tone.
5. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
6. Repeat above step to add additional codes.
7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 103 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 103 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit latch code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 103 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 103 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting latch code and listen for good tone.
7. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 103 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 103 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be added twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

Add Latch Code(s) to Relay A on Wiegand Input 1

These procedures will add a latch code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 103 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 103 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit latch code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 103 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting latch code and listen for good tone.
8. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 103 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.

- Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Latch Code(s) to Relay A on Wiegand Input 2

These procedures will add a latch code or codes to Relay A for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 103 → 1 → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.
- Enter sub mode 6 and listen for good tone.
- Enter 2 (for Wiegand Input 2). No tone will sound.
- Enter next sub mode 103 and listen for good tone.
- Enter next sub mode 1.
- Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
- Repeat above step to add additional codes.
- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 103 → 2 → XXX → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit latch code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 103 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting latch code and listen for good tone.
8. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a

Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 103 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 103 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Access Code(s) to Relay B on Both Wiegand Inputs

These procedures will add an access code or codes to Relay B for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 104 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 104 and listen for good tone.
4. Enter next sub mode 1 and listen for good tone.
5. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
6. Repeat above step to add additional codes.
7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.

- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 104 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 104 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit access code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 104 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 104 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting access code and listen for good tone.
7. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 104 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 104 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be added twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

Add Access Code(s) to Relay B on Wiegand Input 1

These procedures will add an access code or codes to Relay B for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 104 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 104 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 104 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting access code and listen for good tone.
8. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 104 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Access Code(s) to Relay B on Wiegand Input 2

These procedures will add an access code or codes to Relay B for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 104 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 104 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 104 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting access code and listen for good tone.
8. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 104 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 104 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.

- Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Latch Code(s) to Relay B on Both Wiegand Inputs

These procedures will add a latch code or codes to Relay B for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 105 → 1 → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.
- Enter sub mode 6 and listen for good tone.
- Enter next sub mode 105 and listen for good tone.
- Enter next sub mode 1 and listen for good tone.
- Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
- Repeat above step to add additional codes.
- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 105 → 2 → XXX → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 105 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit latch code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 105 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 105 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting latch code and listen for good tone.
7. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a

Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 105 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 105 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be added twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

Add Latch Code(s) to Relay B on Wiegand Input 1

These procedures will add a latch code or codes to Relay B for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 105 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 105 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit latch code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 105 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting latch code and listen for good tone.
8. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).

- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 105 → 4 → Scan First Card → ... → Scan Last Card → #

- Enter Master Code (default 1251) and listen for good tone.
- Enter sub mode 6 and listen for good tone.
- Enter 1 (for Wiegand Input 1). No tone will sound.
- Enter next sub mode 105 and listen for good tone.
- Enter next sub mode 4 and listen for good tone.
- Scan card to be added twice at reader and listen for good tone.
- Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

- Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Add Latch Code(s) to Relay B on Wiegand Input 2

These procedures will add a latch code or codes to Relay B for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 105 → 1 → XXXXX → #

- Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 105 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit latch code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 105 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting latch code and listen for good tone.
8. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 105 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 105 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Change Default Facility Code

These procedures will change the default facility code used for codes added on the Wiegand inputs.

A. Wiegand 1

1251 → 6 → 1 → 106 → XXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 106 and listen for good tone.
5. Enter 3-digit facility code (0 to 255) and listen for good tone.
6. Enter # key to exit Programming Mode.

B. Wiegand 2

1251 → 6 → 2 → 106 → XXX (facility Code) → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 106 and listen for good tone.
5. Enter 3-digit facility code (0 to 255) and listen for good tone.
6. Enter # key to exit Programming Mode.

Add Split-Relay Access Code on Wiegand Inputs

These procedures will add a split-relay access code or codes for Wiegand keypads, card readers, remotes, and vehicle tag readers based on the current split-relay configuration as follows:

- If split-relay function is configured as W1 → Relay A, W2 → Relay A, then split-relay access codes will be added to Relay A on both Wiegand inputs.
- If split-relay function is configured as W1 → Relay A, W2 → Relay B, then split-relay access codes will be added to Relay A on Wiegand Input 1 and Relay B on Wiegand Input 2.
- If split-relay function is configured as W1 → Relay B, W2 → Relay B, then split-relay access codes will be added to Relay B on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more access codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 1 → 107 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.

2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 1. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 107 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 1. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit access code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if Wiegand input is set to SBI Flex 64-bit format.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add access codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 107 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 1. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting access code and listen for good tone.
8. Enter 5-digit ending access code and listen for good tone (maximum of 100 codes).

9. Enter # key to exit Programming Mode.

Note: This procedure will not work if Wiegand input is set to SBI Flex 64-bit format.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more access codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 1 → 107 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 1. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if Wiegand input is set to SBI Flex 64-bit format.

Add Split-Relay Latch Code on Wiegand Inputs

These procedures will add a split-relay latch code or codes for Wiegand keypads, card readers, remotes, and vehicle tag readers based on the current split-relay configuration as follows:

- If split-relay function is configured as W1 → Relay A, W2 → Relay A, then split-relay latch codes will be added to Relay A on both Wiegand inputs.
- If split-relay function is configured as W1 → Relay A, W2 → Relay B, then split-relay latch codes will be added to Relay A on Wiegand Input 1 and Relay B on Wiegand Input 2.
- If split-relay function is configured as W1 → Relay B, W2 → Relay B, then split-relay latch codes will be added to Relay B on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will add one or more latch codes with the default facility code for a Wiegand keypad. Both the 26-bit and SBI Flex 64-bit formats can be used.

1251 → 6 → 2 → 107 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 2. No tone will sound.

4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 107 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 2. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit latch code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if Wiegand input is set to SBI Flex 64-bit format.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will add latch codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 107 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 2. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting latch code and listen for good tone.
8. Enter 5-digit ending latch code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if Wiegand input is set to SBI Flex 64-bit format.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will add one or more latch codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader. Only the 26-bit format can be used.

1251 → 6 → 2 → 107 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 2. No tone will sound.
4. Enter next sub mode 107 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be added twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if Wiegand input is set to SBI Flex 64-bit format.

Delete Code(s) on Both Wiegand Inputs

These procedures will delete codes for Wiegand keypads, card readers, remotes, and vehicle tag readers on both Wiegand inputs.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will delete one or more codes for a Wiegand keypad.

1251 → 6 → 200 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 200 and listen for good tone.
4. Enter next sub mode 1 and listen for good tone.
5. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
6. Repeat above step to add additional codes.
7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will delete one or more codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader.

1251 → 6 → 200 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 200 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit code and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will delete codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader.

1251 → 6 → 200 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 200 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter 3-digit facility code and listen for good tone.
6. Enter 5-digit starting code and listen for good tone.
7. Enter 5-digit ending code and listen for good tone (maximum of 100 codes).
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.

- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will delete one or more codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader.

1251 → 6 → 200 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 200 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Scan card to be deleted twice at reader and listen for good tone.
6. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

7. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- One or both Wiegand inputs are set to SBI Flex 64-bit format.
- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.
- Each Wiegand input is configured to a different Wiegand bit format.
- Split relay feature is enabled.

Delete Code(s) on Wiegand Input 1

These procedures will delete codes for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 1 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will delete one or more codes for a Wiegand keypad.

1251 → 6 → 1 → 200 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 1.

6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will delete one or more codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader.

1251 → 6 → 1 → 200 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will delete codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader.

1251 → 6 → 1 → 200 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.

5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting code and listen for good tone.
8. Enter 5-digit ending code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will delete one or more codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader.

1251 → 6 → 1 → 200 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be deleted twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Delete Code(s) on Wiegand Input 2

These procedures will delete codes for Wiegand keypads, card readers, remotes, and vehicle tag readers on Wiegand Input 2 only.

A. Quick Entry for Wiegand Keypad (uses default facility code)

This procedure will delete one or more codes for a Wiegand keypad.

1251 → 6 → 2 → 200 → 1 → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 1.
6. Enter code (26-bit: 5 digits; numbers only; max value 65535) and listen for good tone.
7. Repeat above step to add additional codes.
8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

B. Quick Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will delete one or more codes with a specified facility code for a Wiegand card reader, remote, or vehicle tag reader.

1251 → 6 → 2 → 200 → 2 → XXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 2 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit code and listen for good tone.
8. Repeat above step to add additional codes.
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

C. Bulk Entry for Wiegand Card Readers, Remotes, and Vehicle Tag Readers

This procedure will delete codes with a specified facility code in bulk for a Wiegand card reader, remote, or vehicle tag reader.

1251 → 6 → 2 → 200 → 3 → XXX → XXXXX → XXXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 3 and listen for good tone.
6. Enter 3-digit facility code and listen for good tone.
7. Enter 5-digit starting code and listen for good tone.
8. Enter 5-digit ending code and listen for good tone (maximum of 100 codes).
9. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.
- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

D. Scan Entry for Wiegand Card Readers and Vehicle Tag Readers

This procedure will delete one or more codes with a specified facility code by scanning for a Wiegand card reader or vehicle tag reader.

1251 → 6 → 2 → 200 → 4 → Scan First Card → ... → Scan Last Card → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter next sub mode 200 and listen for good tone.
5. Enter next sub mode 4 and listen for good tone.
6. Scan card to be deleted twice at reader and listen for good tone.
7. Repeat above step to add additional codes.

Note: Card-to-card swipe timeout is 10 seconds.

8. Enter # key to exit Programming Mode.

Note: This procedure will not work if any of the following are true:

- Wiegand input is set to SBI Flex 64-bit format.

- Wiegand input is disabled.
- Wiegand input is configured to share code list with non-Wiegand codes.
- Split relay feature is enabled.

Set Unit Clock Time

This procedure will set the clock on the Edge unit.

1251 → 6 → 302 → XX (Hours) → XX (Minutes) → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 302 and listen for good tone.
4. Enter hours in 24-hour format (00 to 23) and listen for good tone.
5. Enter minutes (00 to 59) and listen for good tone.
6. Enter # key to exit Programming Mode.

Set Unit Clock Date

This procedure will set the date on the Edge unit.

1251 → 6 → 303 → XX (month) → XX (day of month) → XX (last two digits of year) → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 303 and listen for good tone.
4. Enter month (01 to 12) and listen for good tone.
5. Enter day of month (01 to 31) and listen for good tone.
6. Enter last two digits of year (00 to 99) and listen for good tone.
7. Enter # key to exit Programming Mode.

Configure Split-Relay Function

These procedures will configure the split-relay function.

❗ IMPORTANT! CHANGING THE SPLIT-RELAY CONFIGURATION WILL DELETE ALL WIEGAND CODES INCLUDING MANAGER AND SLEEP CODES!

Note: Enabling split-relay functionality while anti-passback is enabled may cause some undesirable effects.

Note: These procedures will not work if any of the following are true:

- One or both Wiegand inputs are disabled.
- One or both Wiegand inputs are configured to share code list with non-Wiegand codes.

- Each Wiegand input is configured to a different Wiegand bit format.
- Each Wiegand input is configured for SBI Flex 64-bit format but with different code lengths.
- Each Wiegand input is configured for a different Wiegand device type.

A. Disable Split-Relay Function

This procedure will disable the split-relay function.

1251 → 6 → 307 → 0 → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 307 and listen for status tones:
Good tone: Split-relay function disabled
One tone: Mode 1 enabled
Two tones: Mode 2 enabled
Three tones: Mode 3 enabled
4. Enter next sub mode 0 and listen for good tone.
5. Enter Master Code (default 1251) again and listen for good tone.
6. Enter # key to exit Programming Mode.

B. Mode 1 (W1 → A and W2 → A)

When this mode is active, Relay A will be operated by both Wiegand inputs.

1251 → 6 → 307 → 1 → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 307 and listen for status tones:
Good tone: Split-relay function disabled
One tone: Mode 1 enabled
Two tones: Mode 2 enabled
Three tones: Mode 3 enabled
4. Enter next sub mode 1 and listen for good tone.
5. Enter Master Code (default 1251) again and listen for good tone.
6. Enter # key to exit Programming Mode.

C. Mode 2 (W1 → A and W2 → B)

When this mode is active, Relay A will be operated by Wiegand Input 1, and Relay B will be operated by Wiegand Input 2.

1251 → 6 → 307 → 2 → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 307 and listen for status tones:
Good tone: Split-relay function disabled
One tone: Mode 1 enabled
Two tones: Mode 2 enabled
Three tones: Mode 3 enabled
4. Enter next sub mode 2 and listen for good tone.
5. Enter Master Code (default 1251) again and listen for good tone.
6. Enter # key to exit Programming Mode.

D. Mode 3 (W1 → B and W2 → B)

When this mode is active, Relay B will be operated by both Wiegand inputs.

1251 → 6 → 307 → 3 → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 307 and listen for status tones:
Good tone: Split-relay function disabled
One tone: Mode 1 enabled
Two tones: Mode 2 enabled
Three tones: Mode 3 enabled
4. Enter next sub mode 3 and listen for good tone.
5. Enter Master Code (default 1251) again and listen for good tone.
6. Enter # key to exit Programming Mode.

Toggle Silent Mode

This procedure will toggle Silent Mode. When enabled, the Edge unit will not sound audible tones.

1251 → 6 → 309 → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 309 and listen for good tone.
4. Enter Master Code (default 1251) again and listen for good tone.
5. Enter # key to exit Programming Mode.

Configure Anti-Passback

These procedures will configure anti-passback functionality.

Note: Enabling anti-passback while split-relay functionality is enabled may cause some undesirable effects.

Note: The procedures involving Wiegand inputs will not work if the Wiegand inputs involved are disabled.

A. Disable Anti-Passback

This procedure will disable anti-passback.

1251 → 6 → 310 → 0 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.
4. Enter next sub mode 0 and listen for good tone.
5. Enter # key to exit Programming Mode.

B. Enable Timed Lockout for Relay A

This procedure will configure a timed lockout for Relay A after each use.

1251 → 6 → 310 → 1 → XXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.
4. Enter next sub mode 1 and listen for good tone.
5. Enter anti-passback time in seconds (001 to 999) and listen for good tone.
6. Enter # key to exit Programming Mode.

C. Enable Timed Lockout for Relay B

This procedure will configure a timed lockout for Relay B after each use.

1251 → 6 → 310 → 2 → XXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.
4. Enter next sub mode 2 and listen for good tone.
5. Enter anti-passback time in seconds (001 to 999) and listen for good tone.
6. Enter # key to exit Programming Mode.

D. Enable Scheme A (K → W1 or W2)

This procedure will enable Scheme A, in which access must first be granted by the Edge unit

followed by a device on Wiegand Input 1 or 2.

1251 → 6 → 310 → 3 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.
4. Enter next sub mode 3 and listen for good tone.
5. Enter # key to exit Programming Mode.

E. Enable Scheme B (W1 → W2):

This procedure will enable Scheme B, in which access must first be granted by a device on Wiegand Input 1 followed by a device on Wiegand Input 2.

1251 → 6 → 310 → 4 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.
4. Enter next sub mode 4 and listen for good tone.
5. Enter # key to exit Programming Mode.

F. Enable Scheme C (K → W1):

This procedure will enable Scheme C, in which access must first be granted by the Edge unit followed by a device on Wiegand Input 1.

1251 → 6 → 310 → 5 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.
4. Enter next sub mode 5 and listen for good tone.
5. Enter # key to exit Programming Mode.

G. Check Current Anti-Passback Configuration:

This procedure will give the current anti-passback configuration status.

1251 → 6 → 310 → 9 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter next sub mode 310 and listen for good tone.

4. Enter next sub mode 9 and listen for status tones:
Good tone: Anti-passback disabled
One tone: Timed lockout enabled
Two tones: Scheme A enabled
Three tones: Scheme B enabled
Four tones: Scheme C enabled
5. Enter # key to exit Programming Mode.

Configure Wiegand Inputs

These procedures will configure the Wiegand inputs.

❗ IMPORTANT! DISABLING A WIEGAND INPUT WILL DELETE ALL RELATED WIEGAND CODES!

Note: To enable a Wiegand input as a vehicle tag reader, use the Edge Smart Keypad app.

Note: If either the anti-passback or split-relay feature is enabled, disable it before disabling any Wiegand inputs.

A. Wiegand Input 1

1251 → 6 → 1 → 500 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter secondary sub mode 500 and listen for good tone.
5. Enter 0 to disable and listen for good tone.
Enter 1 to enable as keypad and listen for good tone.
Enter 2 to enable as card reader and listen for good tone.
Enter 3 to enable as remote and listen for good tone.
6. Enter # key to exit Programming Mode.

B. Wiegand Input 2

1251 → 6 → 2 → 500 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter secondary sub mode 500 and listen for good tone.
5. Enter 0 to disable and listen for good tone.
Enter 1 to enable as keypad and listen for good tone.
Enter 2 to enable as card reader and listen for good tone.

Enter 3 to enable as remote and listen for good tone.

6. Enter # key to exit Programming Mode.

Configure Wiegand Bit Format

These procedures will configure the Wiegand bit format for Wiegand codes.

❗ IMPORTANT! COMPLETING THESE PROCEDURES WILL DELETE ALL WIEGAND CODES!

Note: The SBI Flex 64-bit format is only available for inputs configured as Wiegand keypads.

A. Both Wiegand Inputs

1251 → 6 → 501 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter secondary sub mode 501 and listen for good tone.
4. Enter 1 (for 26-bit format) or 2 (for SBI Flex 64-bit format) and listen for good tone.
5. Enter # to exit Programming Mode.

B. Wiegand Input 1

1251 → 6 → 502 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter secondary sub mode 502 and listen for good tone.
4. Enter 1 (for 26-bit format) or 2 (for SBI Flex 64-bit format) and listen for good tone.
5. Enter # to exit Programming Mode.

C. Wiegand Input 2

1251 → 6 → 503 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter secondary sub mode 503 and listen for good tone.
4. Enter 1 (for 26-bit format) or 2 (for SBI Flex 64-bit format) and listen for good tone.
5. Enter # to exit Programming Mode.

Note: These procedures will not work if any of the following are true:

- Wiegand input is disabled.
- Split relay feature is enabled.

Configure Wiegand Code Scheme

These procedures will configure the scheme to be followed for Wiegand codes. Wiegand codes can be set to exist as standard keypad codes as well or to be kept separate on a different list.

❗ IMPORTANT! COMPLETING THESE PROCEDURES WILL DELETE ALL WIEGAND CODES!

A. Wiegand Input 1

1251 → 6 → 1 → 504 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter secondary sub mode 504 and listen for good tone.
5. Enter 1 (for same as keypad codes) or 2 (for different codes) and listen for good tone.
6. Enter # to exit Programming Mode.

B. Wiegand Input 2

1251 → 6 → 2 → 504 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter secondary sub mode 504 and listen for good tone.
5. Enter 1 (for same as keypad codes) or 2 (for different codes) and listen for good tone.
6. Enter # to exit Programming Mode.

C. Both Wiegand Inputs

1251 → 6 → 3 → 504 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 3 (for both Wiegand inputs). No tone will sound.
4. Enter secondary sub mode 504 and listen for good tone.
5. Enter 1 (for same as keypad codes) or 2 (for different codes) and listen for good tone.
6. Enter # to exit Programming Mode.

Note: These procedures will not work if any of the following are true:

- Wiegand input is disabled.
- Split relay feature is enabled.

Configure Wiegand Validation Method

These procedures will configure the validation method used on the Wiegand inputs.

A. Wiegand Input 1

1251 → 6 → 1 → 505 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter secondary sub mode 505 and listen for good tone.
5. Enter 1 (for validate facility and access code) or 2 (for validate access code only) and listen for good tone.
6. Enter # to exit Programming Mode.

B. Wiegand Input 2

1251 → 6 → 2 → 505 → X → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter secondary sub mode 505 and listen for good tone.
5. Enter 1 (for validate facility and access code) or 2 (for validate access code only) and listen for good tone.
6. Enter # to exit Programming Mode.

Change Wiegand Code Length

These procedures will change the code length on the Wiegand inputs from 4 to 11 digits.

⚠ IMPORTANT! COMPLETING THESE PROCEDURES WILL DELETE ALL WIEGAND CODES!

Note: This option is only available with the SBI Flex 64-bit format selected.

A. Wiegand Input 1

This procedure will set the code length for Wiegand Input 1.

1251 → 6 → 1 → 506 → XX → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 1 (for Wiegand Input 1). No tone will sound.
4. Enter secondary sub mode 506 and listen for good tone.

5. Enter length value (04 to 11) and listen for good tone.
6. Enter Master Code (default 1251) again and listen for good tone.
7. Enter # key to exit Programming Mode.

B. Wiegand Input 2

This procedure will set the code length for Wiegand Input 2

1251 → 6 → 2 → 506 → XX → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 6 and listen for good tone.
3. Enter 2 (for Wiegand Input 2). No tone will sound.
4. Enter secondary sub mode 506 and listen for good tone.
5. Enter length value (04 to 11) and listen for good tone.
6. Enter Master Code (default 1251) again and listen for good tone.
7. Enter # key to exit Programming Mode.

Note: These procedures will not work if any of the following are true:

- Wiegand input is disabled.
- Split relay feature is enabled.

Add Access Code(s) to Relay B

This procedure will add one or more access codes to Relay B.

Note: By default, the following codes are reserved for other functions and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 7 → XXXX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 7 and listen for good tone.
3. Enter code (4 digits by default; numbers only) to be added and listen for good tone.
4. Repeat above step to add additional codes.
5. Enter # key to exit Programming Mode.

Add Limited-Use Code

This procedure will add a limited-use code restricted by number of uses or time in hours.

Note: By default, the following codes are reserved for other functions and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

1251 → 8 → X → XXXX → XX → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 8 and listen for good tone.
3. Enter 1 for use restriction or 2 for time restriction and listen for good tone.
4. Enter the code with configured length and listen for good tone.
5. Enter number of uses (01 to 99) or number of hours (01 to 24).
6. Enter # key to exit Programming Mode.

Enter Pairing Mode

This procedure will start a 90-second timer for first-time administrator pairing with the Edge unit.

1251 → 9 → 1 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 9 and listen for good tone.
3. Enter 1 and listen for good tone.
4. Enter # key to exit Programming Mode.

Delete All Codes and Timers

This procedure will delete all codes and timers.

❗ IMPORTANT! COMPLETING THIS PROCEDURE WILL DELETE ALL CODES AND TIMERS!

1251 → 0 → 1251 → #

1. Enter Master Code (default 1251) and listen for good tone.
2. Enter sub mode 0 and listen for good tone.
3. Enter Master Code again and listen for good tone (wait until good tone is received).
4. Enter # key to exit Programming Mode.

Master Code Reset

This procedure will reset the Master Code to the default value. No other stored data is affected.

1. Open unit.
2. Locate, press, and hold down Factory Reset (FAC. RST.) button on main circuit board (located in group with other buttons).
3. While still holding Factory Reset button, press star (*) key 3 times on Edge unit keypad and listen for good tone.
4. Release Factory Reset button.

The Master Code is now set to the default value (1251).

Unit Reset

This procedure will reset the Edge unit back to factory settings, erasing the codes and timers in memory and resetting the Master Code back to the default value.

❗ IMPORTANT! THIS PROCEDURE WILL RESET THE EDGE UNIT TO FACTORY SETTINGS AND ERASE ALL STORED INFORMATION, INCLUDING CODES AND TIMERS!

1. Open unit and locate, press, and hold down Factory Reset (FAC. RST.) button on main circuit board (located in group with other buttons). Hold down for about 10 seconds until three (3) beeps sound.
2. While still holding Factory Reset button, press pound-star-pound (#*#) on Edge unit keypad and listen for good tone.
3. Enter current Master Code (default 1251). After about 15 seconds, Edge unit will start sounding a continuous cycle of tones to indicate all data has been deleted.
4. Power off Edge unit and immediately power back on.

The Edge unit is now reset to factory settings.


Technical Support

Need Help?

Call **(972) 474-6390**

Email **techsupport@securitybrandsinc.com**

We are available Monday through Friday from 8 am to 5 pm Central Time.



EDGE SMART KEYPAD APP

Unlock even more advanced functionality on your smart keypad or card reader with our mobile administrator app, available for Apple iOS and Android.

APP FEATURES

- Full access control management
- Relay control (open, latch/unlatch)
- Limited-use codes with use, 7-day, and 365-day restrictions
- 7-day, 365-day, holiday, and special event timers (separate timers for each relay)
- Random code generator
- Event reports with CSV export
- Event input configuration
- Digital input configuration
- Quick cloning for multiple-unit setups

GET THE EDGE SMART KEYPAD APP

