







































## H Reset Procedures

**NOTE:** If an error is made during these procedures, an “error” tone will sound, and you must start again from the beginning.

### Master Code Reset

This procedure will reset the Master Code to the default value. No other stored data will be affected.

**Step 1 - Open door on unit.**

**Step 2 - Locate, press, and hold Factory Reset (FAC. RST.) Button.**

Hold down for about 10 seconds until three (3) beeps sound.

**Step 3 - While still holding Factory Reset (FAC. RST.) Button, press star key (\*) on Programming Pad three (3) times.**

Unit will sound good tone if successful.

**Step 4 - Release Factory Reset (FAC. RST.) Button.**

The Master Code is now reset to the default value (1251).

### Unit Reset

This procedure will reset the unit back to factory settings. It will erase all codes and timers in memory and reset the Master Code back to the default value.

**⚠ IMPORTANT! THIS PROCEDURE WILL RESET THE UNIT TO FACTORY SETTINGS AND ERASE ALL STORED INFORMATION, INCLUDING CODES AND TIMERS!**

**Step 1 - Open door on unit.**

**Step 2 - Locate, press, and hold Factory Reset (FAC. RST.) Button.**

Hold down for about 10 seconds until three (3) beeps sound.

**Step 3 - While still holding Factory Reset (FAC. RST.) Button, press pound-star-pound (\*\*\*) on Programming Pad**

Unit will sound good tone if successful. Release Factory Reset Button.

**Step 4 - Enter Master Code (default 1251) on Programming Pad.**

After about 15 seconds, unit will start sounding a continuous cycle of tones to indicate all data has been deleted.

**Step 5 - Power off unit and immediately power back on.**

The unit is now reset to factory settings.

