Leave with system owner

1

Sign up for plan and complete activation steps.

Go to **summitcontrol.com** and follow the steps given in the **Activation Guide**.

Install, wire, power on, and test* unit(s). Leave unit(s) powered on for initial setup by Summit Control.

Refer to the **Install Guide**. A professional installer is recommended for installation.

* Only models with keypads can be tested before activation.

- Same-day activation will occur if we receive your request by 3 pm Central, Mon-Fri.
- Once activated, you may go to your admin dashboard to set up your Ascent unit(s).

Available features vary depending on Ascent model.